

# Ignition Edge Panel

## Hub-and-Spoke with Local Client Fallback

Use Ignition Edge Panel to create local client fallback with store-and-forward functionality at the edge of the network, with unlimited tags. If a network connection between Ignition Edge and the central Ignition server (with EAM installed) is severed, Edge can store tag history for 35 days. When the connection is restored, Ignition Edge will synchronize data back to the central Ignition server.

